

sorenmobler

Bed Frame Assembly Instructions

Aria | Havelock | Milford | Opera | Verso | River Crossings

Included Components

- ☐ 1 × Headboard
- ☐ 1 × Tailboard
- ☐ 2 × Side Rails
- ☐ 1 × Centre Rail
- ☐ 1 × Set of Slats
- ☐ 10 × Screws (8 x 1¼ inch)

Assembly Instructions (pictures on page 2)

1. Position the Headboard

- Place the headboard in the desired location in the room.

2. Attach Side Rails

- Take a Side Rail and align its bracket with the bracket on the Headboard.
- Slide the Side Rail bracket firmly into the Headboard bracket until fully engaged.
- Repeat this process for both sides.
- **Tip:** The cleat on the inside of the Side Rail should face upward, near the top edge.

3. Attach the Tailboard

- Repeat the same process to connect the Tailboard to the opposite ends of both Side Rails.

4. Attach the Tailboard

- Repeat the same process to connect the Tailboard to the opposite ends of both Side Rails.

5. Secure All Connections

- Gently but firmly tap all rails downward to confirm all brackets are fully locked together.

6. Install the Slats

- Place the bundled slats on the bed frame and unwrap them.
- Slide the slats evenly along the frame, spacing them consistently from one end to the other.
- Optionally, for added stability, you may screw the end slats into the bed frame (this step is not required).

7. Final Check

- Ensure all bolts and screws are securely tightened.

 **Your Bed Frame is now ready for use!**

sørenmobler

3.



Bracket on Headboard and Tail Board



Bracket on Side Rails



Example of Side Rail bracket attached to Headboard bracket

4.



Centre Rail Bracket



Centre Rail in place



It should look like this

Sorensen Furniture Company
26 London Street, PO Box 5005,
Wanganui 4542, New Zealand
Tel. (06) 349 0460 Fax. (06) 343 7415
sales@sorenmobler.co.nz
www.sorenmobler.co.nz

