

sørenmobler

Ashfield Float Bed Frame Assembly Instructions

Included Components

- ☐ 1 × Headboard
- ☐ 2 × Side Rails
- ☐ 1 × Metal Float End Rail
- ☐ 1 × Tail Board
- ☐ 1 × Centre Rail
- ☐ 1 × Set of Slats
- ☐ 10 × 8x¼" Screws
- ☐ 4 × Float Frame Bolts
- ☐ 4 × Washers
- ☐ 8 × Side Rail Bolts
- ☐ 1 × 5mm Allen Key

Assembly Instructions (pictures on page 2)

1. Position the Headboard

- Place the headboard in the desired location in the room.

2. Attach the Side Rails

- Unwrap the side rails and position them at each side of the headboard.
- Secure using the side rail bolts provided.

3. Install the Metal Float End Rail

- Position the metal float end rail at the foot of the bed.
- Align the bolt holes and loosely fasten the float frame bolts and washers. Do not fully tighten yet.

4. Attach the Tail Board

- Secure the tail board to the side rails using the bolts provided.

5. Tighten Float Frame Connections

- Once all components are aligned, fully tighten the float frame bolts.

6. Insert the Centre Rail

- Position the centre rail securely between the headboard and tail board.

7. Install the Slats

- Unpack the slat set and lay them evenly across the side rails.
- Use the 8x¼" screws to fasten the slats into place.

8. Final Check

- Ensure all bolts and screws are securely tightened.

 **Your Ashfield Float Bed Frame is now ready for use!**

sørenmobler

2.



3.



4.



6.



Sorensen Furniture Company
26 London Street, PO Box 5005,
Wanganui 4542, New Zealand
Tel. (06) 349 0460 Fax. (06) 343 7415
sales@sorenmobler.co.nz
www.sorenmobler.co.nz

