

sørenmobler

CHATEAU, LOUIS BED FRAME ASSEMBLY INSTRUCTIONS

Tools Required:

Pozi Drive Screwdriver or Phillips head Screwdriver

1. Screw bolts into sockets of the headboard and tailboard
2. Slide the Bed Side rails over the exposed bolts, make sure all bolt holes and grooves are at the bottom side of the rail.
3. Insert the 1/2 round metal packer over the end of the bolt that is visible in the cavity on the side rail and then screw the nut up tight on to the bolt.
4. Tighten all bolts to the side rails and headboard/tailboard.
5. Screw corner brackets onto the headboard and side rails and Tailboard and side rails, then the support bracket onto the middle of the side rail.
6. Unwrap the slat frame and fit the 2 adjustable feet to the underside of slat frame
7. Place the slat frame into the Bed
8. Adjust the feet on the slat frame to touch the floor
9. Place mattress into the bed



Sorensen Furniture Company
26 London Street, PO Box 5005,
Wanganui 4542, New Zealand
Tel. (06) 349 0460 Fax. (06) 343 7415

sales@sorenmobler.co.nz
www.sorenmobler.co.nz