

# sorenmobler

## Huntsman Bed Frame Assembly Instructions

### Included Components

- ☐ 1 × Headboard
- ☐ 2 × Side Rails
- ☐ 1 × Tail Board
- ☐ 1 × Centre Rail
- ☐ 1 × Set of Slats
- ☐ 10 × 8x¼" Screws
- ☐ 8 × Side Rail Bolts
- ☐ 1 × 5mm Allen Key

### Assembly Instructions

- 1. Position the Headboard**
  - Place the headboard in the desired location in the room.
- 2. Attach the Side Rails**
  - Unwrap the side rails and position them at each side of the headboard.
  - Secure using the side rail bolts provided.
- 3. Attach the Tail Board**
  - Secure the tail board to the side rails using the bolts provided.
- 4. Tighten Frame Connections**
  - Once all components are aligned, fully tighten the frame bolts.
- 5. Insert the Centre Rail**
  - Position the centre rail securely between the headboard and tail board.
- 6. Install the Slats**
  - Unpack the slat set and lay them evenly across the side rails.
  - Use the 8x¼" screws to fasten the slats into place.
- 7. Final Check**
  - Ensure all bolts and screws are securely tightened.

✓ **Your Huntsman Bed Frame is now ready for use!**

Sorensen Furniture Company  
26 London Street, PO Box 5005,  
Wanganui 4542, New Zealand  
Tel. (06) 349 0460 Fax. (06) 343 7415  
sales@sorenmobler.co.nz  
www.sorenmobler.co.nz

