

# sørenmobler

## Float Bed Frame Assembly Instructions

Muriwai | Riverwood

### Included Components

- ☐ 1× Headboard
- ☐ 2× Side Rails
- ☐ 1× Metal Float End Rail
- ☐ 1× Tail Board
- ☐ 1× Centre Support Rail
- ☐ 1× Set of Slats
- ☐ 10× Screws (8×¼")
- ☐ 4× Bolts
- ☐ 4× Washers
- ☐ 1× 5mm Allen Key

### Assembly Instructions (pictures on page 2)

#### 1. Position the Headboard

- Place the headboard in the desired location in the room.

#### 2. Attach the Side Rails

- Unwrap the side rails and align them with the headboard brackets. Gently tap down to secure them into the pre-cut slots.

#### 3. Install the Metal Float End Rail

- Place the metal float frame at the foot of the bed. Align the bolt holes and loosely insert the bolts with washers.
- Do not fully tighten yet.

#### 4. Attach the Tail Board

- Connect the tail board to the ends of the side rails, ensuring a snug fit.

#### 5. Tighten Float Frame Bolts

- Once everything is aligned, fully tighten the float frame bolts using the provided Allen key.

#### 6. Insert the Centre Support Rail


- Place the centre rail between the headboard and the tail board, ensuring it is properly seated.

#### 7. Secure the Slats

- Unwrap the slats and place them evenly across the bed frame. Screw them into the side rails using the 8×¼" screws provided.

#### 8. Final Check

- Ensure all bolts and screws are tightened securely

 Your Muriwai/Riverwood Float Bed Frame is now ready for use!

# sørenmobler

2.



3.



4.



Sorensen Furniture Company  
26 London Street, PO Box 5005,  
Wanganui 4542, New Zealand  
Tel. (06) 349 0460 Fax. (06) 343 7415  
[sales@sorenmobler.co.nz](mailto:sales@sorenmobler.co.nz)  
[www.sorenmobler.co.nz](http://www.sorenmobler.co.nz)

