

sorenmobler

Omaha Bed Frame Assembly Instructions

Included Components

- ☐ 1 × Headboard
- ☐ 1 × Tailboard (Footboard)
- ☐ 2 × Side Rails
- ☐ 1 × Centre Rail
- ☐ 1 × Timber Slat Pack
- ☐ 8 × Bolts
- ☐ 8 × Nuts
- ☐ 8 × Half-Moon Packers
- ☐ 4 × Dowels

Assembly Instructions

- 1. Position the Headboard & Tailboard**
 - Place the headboard in the desired location in the room & the tailboard face down at the foot of the bed area.
- 2. Install Hardware**
 - Screw the threaded rods into the inserts on both the headboard and tailboard.
 - Insert the wooden dowels into the 8mm holes next to the rods.
- 3. Attach Side Rails (Headboard Side First)**
 - Slide each side rail over the bolts and dowels on the headboard.
 - Ensure the timber cleat is positioned at the top and the cutout is at the tailboard end.
- 4. Connect to Tailboard**
 - Slide the tailboard onto the exposed bolts and dowels at the other end of the side rails.
- 5. Final Frame Check**
 - Confirm all 8 nuts are tightened and the frame is stable and secure.
- 6. Install Centre Rail**
 - Position the centre rail into the brackets on the headboard and tailboard.
- 7. Lay Timber Slats**
 - Unpack the slat pack and spread the slats across the centre rail and cleats on both side rails.
- 8. Space and Secure Slats**
 - Evenly space the slats along the frame.
 - Screw down the first and last slats to lock the position.

 **Your Omaha Bed Frame is now ready for use!**