

# sorenmobler

## Orakei Bed Frame Assembly Instructions

### Included Components

- ☐ 1 × Headboard
- ☐ 1 × Tailboard (Footboard)
- ☐ 2 × Side Rails
- ☐ 1 × Centre Rail
- ☐ 1 × Timber Slat Pack
- ☐ 8 × Bolts
- ☐ 8 × Nuts
- ☐ 8 × Half-Moon Packers
- ☐ 4 × Dowels

### Assembly Instructions

#### 1. Position the Headboard & Tailboard

- Place the headboard in the desired location in the room & the tailboard face down at the foot of the bed area.

#### 2. Install Hardware

- Screw the threaded rods into the inserts on both the headboard and tailboard.
- Insert the wooden dowels into the 8mm holes next to the rods.

#### 3. Attach Side Rails (Headboard Side First)

- Slide each side rail over the bolts and dowels on the headboard.
- Ensure the timber cleat is positioned at the top.

#### 4. Connect to Tailboard

- Slide the tailboard onto the exposed bolts and dowels at the other end of the side rails.

#### 5. Secure with Half-Moon Packers & Nuts

- Place a half-moon packer over each visible bolt inside the side rails (in the cutout area).
- Screw on the nuts and tighten them securely.

#### 6. Final Frame Check

- Confirm all 8 nuts are tightened and the frame is stable and secure.

#### 7. Install Centre Rail

- Position the centre rail into the brackets on the headboard and tailboard.

#### 8. Lay Timber Slats

- Unpack the slat pack and spread the slats across the centre rail and cleats on both side rails.

#### 9. Space and Secure Slats

- Evenly space the slats along the frame.
- Screw down the first and last slats to lock the position.

 **Your Orakei Bed Frame is now ready for use!**