

sorenmobler

SOLARIS BED ASSEMBLY INSTRUCTIONS

COMPONENTS REQUIRED:

- 1 x headboard
- 1 x Tailboard
- 2 x Side Rails
- 1 x Centre Rail
- 1 x Timber Slat Pack
- 8 x Bolts
- 8 x Nuts
- 8 x ½ Moon Packers
- 8 x Dowels

1. Unpack all pieces, place the headboard against the wall of the bedroom and the tailboard on its face at the end of the bed
2. Screw the threaded rods into the inserts in the headboard and the tailboard and insert the dowels into the 8mm holes.
3. Slide the side rail over the bolts and dowels on the headboard end first. The side rail must have the timber cleat to the top and to have the cut out at the tailboard end
4. Slide both side rails over the headboard bolts then slide the tailboard end onto the other end of the side rails
5. Place the ½ moon packer over the bolt which will be showing in the cutout on the inside of the side rails, screw the nut on next and tighten.
6. At the tailboard end the small section of timber cleat will need to be undone to enable you to fit the packer and nut, refit the cleat when the nut is tight.
7. The bed should now have all 8 nuts done up and be firm
8. Place the Centre rail into the bed brackets on the headboard and the tailboard
9. Unpack the slats and place over the centre rails and onto the cleats
10. Stretch the timber slats out over the bed till they are evenly spaced, screw the top and end slat to fix them in position
11. Your bed is now ready for the mattress to be placed on to it.



Sorensen Furniture Company
26 London Street, PO Box 5005,
Wanganui 4542, New Zealand
Tel. (06) 349 0460 Fax (06) 343 7415
sales@sorenmobler.co.nz
www.sorenmobler.co.nz